



# ECO SPEC<sup>®</sup> WB

INTERIOR LATEX

## PEARL FINISH F375

### Features

- Minimal Odour
- Zero VOC's
- Quick return to service
- Spatter-resistant
- 100% Acrylic
- Dries quickly to a beautiful pearl finish with the washability of a semi-gloss

### Recommended For

For use on primed or previously painted drywall, masonry, plaster, wood, metal and wallpapered surfaces. Use Eco Spec<sup>®</sup> WB Interior Latex Primer (F372) as a first coat when a low odour, solvent free primer/ finish system is desired.

### General Description

A low odour, zero VOC, 100% acrylic interior latex pearl finish that provides a high hiding, excellent touch up and a uniform pearl finish. Its resulting film combines the beauty of a Pearl finish with washability of a semi-gloss finish. Eco Spec<sup>®</sup> WB Interior Latex Pearl Finish (F375) is ideally suited for commercial, facility management and residential applications. Eco Spec<sup>®</sup> WB Interior Latex Pearl Finish (F375) does not have the odour of conventional paints that contain ingredients known as Volatile Organic Compounds (VOC's).

### Limitations

- Do not paint when temperature of air and surface is below 10° C (50 °F).

### Product Information

**Colours:—Standard:**  
White (01)

**—Tint Bases:**  
Gennex<sup>®</sup> Waterborne Colorant Bases 1X, 2X, 3X and 4X.

**—Special Colours:**  
Contact your Benjamin Moore representative

### Certification:

VOC compliant in all regulated areas



The Green Promise<sup>®</sup> designation means that this product has been tested by independent third parties and meets or exceeds each standard shown in the first row of the following chart.

LEED <sup>®</sup>	CHPS (Collaborative for High Performance Schools)	VOC (in any color)
YES	YES	0 g/L

Products that have the Green Promise<sup>®</sup> designation also meet or exceed the published chemical restriction and performance criteria included in the standards shown below, based on independent, third-party testing, but have not been certified under any of these standards.

Green Seal <sup>™</sup> GS-11 2010	Eco Logo <sup>™</sup> / Environmental Choice <sup>™</sup>
YES	YES

### Technical Data<sup>◇</sup>

Vehicle Type	Pastel Base
Vehicle Type	100% Acrylic Latex
Pigment Type	Titanium Dioxide
Volume Solids	38%

Coverage per 3.79 L at	37.2 – 41.8 sq. m.
Recommended Film Thickness	(400 – 450 sq. ft.)

Recommended Film Thickness	– Wet	3.8 mils
	– Dry	1.4 mils

Depending on surface texture and porosity. Be sure to estimate the right amount of paint for the job. This will ensure colour uniformity and minimize the disposal of excess paint

Dry Time @ 25 °C (77 °F) @ 50% RH	– To Touch	½ to 1 Hour
	– To Recoat	1 to 2 Hours

Painted surfaces can be washed after two weeks. High humidity and cool temperatures will result in longer dry, recoat and service times

Dries By Evaporation, Coalescence

Viscosity 90 ± 2 KU

Flash Point None

Gloss / Sheen Pearl (15-20 @ 60 °)

Surface Temperature at Application	– Min.	10 °C (50 °F)
	– Max	32.2 °C (90 °F)

Thin With See Chart

Clean Up Thinner Clean Water

Weight Per 3.79 L 4.8 kg (10.5 lbs)

Storage Temperature	– Min.	4.4 °C (40 °F)
	– Max	32.2 °C (90 °F)

### Volatile Organic Compounds (VOC)

0 g/L

**-Zero VOC post tint (any base and any colour)**

### Customer Service Information Centre

1-800-361-5898, [info@benjaminmoore.ca](mailto:info@benjaminmoore.ca), [www.benjaminmoore.ca](http://www.benjaminmoore.ca)

<sup>◇</sup>Reported values are for Pastel Base. Contact Benjamin Moore for values of other bases or Colours.

**Surface Preparation**

Surfaces to be painted must be clean, dry, and free of dirt, dust, grease, oil, soap, wax, scaling paint, water soluble materials, and mildew. Remove any peeling or scaling paint and sand these areas to feather edges smooth with adjacent surfaces. Glossy areas should be dulled. Drywall surfaces must be free of sanding dust.

New plaster or masonry surfaces must be allowed to cure (30 days) before applying base coat. Cured plaster should be hard, have a slight sheen and maximum pH of 10; soft, porous or powdery plaster indicates improper cure. Never sand a plaster surface; knife off any protrusions and prime plaster before and after applying patching compound. Poured or pre-cast concrete with a very smooth surface should be etched or abraded to promote adhesion, after removing all form release agents and curing compounds. Remove any powder or loose particles before priming.

**Difficult Substrates:** Benjamin Moore® offers a variety of specialty primers for use over difficult substrates such as plaster, bleeding woods, grease stains, crayon markings, hard glossy surfaces, galvanized metal or other substrates where paint adhesion or stain suppression is a particular problem. Your Benjamin Moore® retailer can recommend the right problem-solving primer for your special needs.

**WARNING!** If you scrape, sand or remove old paint, you may release lead dust. **LEAD IS TOXIC. EXPOSURE TO LEAD DUST CAN CAUSE SERIOUS ILLNESS, SUCH AS BRAIN DAMAGE, ESPECIALLY IN CHILDREN. PREGNANT WOMEN SHOULD ALSO AVOID EXPOSURE.** Wear a NIOSH-approved respirator to control lead exposure. Carefully clean up with a HEPA vacuum and a wet mop. Before you start, find out how to protect yourself and your family by logging onto Health Canada @ [http://www.hc-sc.gc.ca/iyh-vsv/prod/paint-peinture\\_e.html](http://www.hc-sc.gc.ca/iyh-vsv/prod/paint-peinture_e.html).

**Primer/Finish Systems**

Eco Spec® WB Interior Latex Primer (F372) is the preferred primer in most situations. For best hiding results use Eco Spec® WB Primer tinted to the approximate finish coat colour. **Special Note:** Certain custom Colours require a Deep Colour Base Primer tinted to a special prescription formula to achieve the desired colour. Consult your retailer.

**Wood, and engineered wood products**

**Primer:** Eco Spec® WB Interior Latex Primer (F372) or Fresh Start® All Purpose Alky Primer (K024)

**Finish:** 1 or 2 coats Eco Spec® WB Interior Latex Pearl Finish (F375)

**Drywall**

**Primer:** Eco Spec® WB Interior Latex Primer (F372)

**Finish:** 1 or 2 coats Eco Spec® WB Interior Latex Pearl Finish (F375)

**Plaster**

**Primer:** Eco Spec® WB Interior Latex Primer (F372)

**Finish:** 1 or 2 coats Eco Spec® WB Interior Latex Pearl Finish (F375)

**Rough or Pitted Masonry**

**Primer:** Super Spec® Latex Block Filler (K160) or Super Spec® Masonry Interior/Exterior Hi-Build Block Filler (K206)

**Finish:** 1 or 2 coats Eco Spec® WB Interior Latex Pearl Finish (F375)

**Smooth Poured or Pre-cast Concrete**

**Primer:** Eco Spec® WB Interior Latex Primer (F372)

**Finish:** 1 or 2 coats Eco Spec® WB Interior Latex Pearl Finish (F375)

**Unpainted Metal (Ferrous)**

**Primer:** Super Spec HP® Acrylic Metal Primer (KP04), Super Spec HP® Alkyd Metal Primer (KP06) or Fresh Start® Rust Inhibitive Primer (K163)

**Finish:** 1 or 2 coats Eco Spec® WB Interior Latex Pearl Finish (F375)

**Non-Ferrous Metal (Galvanized & Aluminium)** All new metal surfaces must be thoroughly cleaned with Super Spec HP® Oil & Grease Emulsifier (KP83) to remove contaminants. New shiny non-ferrous metal surfaces that will be subject to abrasion should be dulled with very fine sandpaper or a synthetic steel wool pad to promote adhesion

**Primer:** Super Spec HP® Acrylic Metal Primer (KP04)

**Finish:** 1 or 2 coats Eco Spec® WB Interior Latex Pearl Finish (F375)

**Repaint, All Substrates:** Prime bare areas with the primer recommended above for the substrate

**Application**

**Mixing of Paint:** Stir thoroughly before and during use. Apply one or two coats. Use the same brushing techniques as you would for any zero-VOC compliant interior coating. For best results, use a premium Benjamin Moore® custom-blended nylon/polyester brush, premium Benjamin Moore® roller or a similar product. Apply paint generously from unpainted area into wet area. Eco Spec® WB dries faster than other acrylic paints, so avoid lap marks by maintaining a wet edge.

This product can also be sprayed; refer to the chart below for spray recommendations.

**Thinning/Cleaning**

Conditioning with Benjamin Moore® K518 Extender may be necessary under certain conditions to adjust open time or spray characteristics. The chart below is for general guidance		
	<b>Mild conditions</b> Humid (RH> 50%) with no direct sunlight & with little to no wind	<b>Severe conditions</b> Dry (RH<50%), in direct sunlight, or windy conditions
<b>Brush:</b> Nylon / Polyester	No thinning necessary	Add <b>K518 Extender</b> or <b>water:</b>
<b>Roller:</b> Premium Quality		Max of 236 ml (8 fl. oz.) to a 3.79 L
<b>Spray: Airless</b> Pressure: 1500 -2500 psi Tip: 0.013-0.017		<b>Never add other paints or solvents.</b>

**Cleanup:** Wash brushes, rollers, and other painting tools in warm, soapy water immediately after use. Spray equipment should be given a final rinse with mineral spirits to prevent rusting.

**USE COMPLETELY OR DISPOSE OF PROPERLY.** Dry, empty containers may be recycled in a can recycling program. Local disposal requirements vary; consult your sanitation department or state-designated environmental agency on disposal options.

**Environmental, Health & Safety Information**

**Use only in a well ventilated area.** Keep container closed when not in use. In case of spillage, absorb with inert material and dispose of in accordance with local regulations. Wash thoroughly after handling.

**KEEP OUT OF REACH OF CHILDREN  
PROTECT FROM FREEZING**

**Refer to Material Safety Data Sheet for additional health and safety information.**