

ARBORCOAT® WATERBORNE ULTRA FLAT SOLID STAIN 610

Features

- Beautiful rustic ultra flat finish
- Suitable for use on all types of wood and properly cured stucco, masonry, manufactured and fiber-cement siding
- Specially formulated to resist mildew growth on the coating
- Excellent touch up and re-coat properties
- Hides imperfections on exterior surfaces with an ultra-flat finish
- Easy to use with soap and water clean up

General Description

A premium ultra-flat solid stain which masks the grain of the wood without obscuring its texture. This durable finish protects and enhances the appearance of new or previously stained smooth or rough siding, manufactured hardboard and fiber-cement siding, shakes, trim, railings, fencing, stucco and masonry. The ultra flat finish minimizes exterior imperfections while maintaining excellent color retention properties.

Recommended For

Residential or commercial applications where a premium quality finish is desired. Use on new or previously stained smooth or rough siding, manufactured hardboard and fibercement siding, shakes, trim, railings, fencing, stucco and masonry.

Limitations

- Do not apply when air and surface temperatures are below 40°F (4.4°C).
- · Do not apply to surfaces such as outdoor furniture or decks

Pastel Base

Clean Water

11.43 lbs

40°F

90°F

100% Acrylic Latex

Do not paint vinyl siding darker than the original color

cement siding, shakes, trim, railings, fencing, stucco and masonry.	 Do not paint vinyl siding 		
Product	Product Information		
Colors: —Standard:	Technical Data◊		
White (1X)	Vehicle Type		
	Pigment Type		
	Volume Solids		
—Tint Bases: Benjamin Moore® Gennex® bases 1X, 2X, 3X, & 4X	Coverage per Gallon a Recommended Film T		
	Recommended Film		
—Special Colors:	Thickness		
Contact your Benjamin Moore representative	Depending on surface te the right amount of pai uniformity and minimize th		
Certification:	Dry Time @ 77°F (25°C) @ 50% RH		
VOC compliant in all regulated areas. Master Painters Institute MPI #16	High humidity and cool recoat and service times.		
	Dries By		
	Viscosity		
	Flash Point		
	Gloss / Sheen		
	Surface Temperature at Application		
Technical Assistance	Thin With		
Available through your local authorized Benjamin Moore® retailer. F the location of the retailer nearest you, call 1-800-826-2623, see	Clean Up Thinner		
www.benjaminoore.com, or consult your local Yellow Pages	Weight Per Gallon		
	Storage Temperature		

Pigment Type		Titanium Dioxide	
Volume Solids		32%	
Coverage per Gallon a Recommended Film T		200 – 400 Sq. Ft.	
Recommended Film Thickness	– Wet – Dry	5.3 mils 1.7 mils	
Depending on surface texture and porosity. Be sure to estimate the right amount of paint for the job. This will ensure color uniformity and minimize the disposal of excess paint.			
Dry Time @ 77°F (25°C) @ 50% RH	To TouchTo Recoat	1 Hour 3 – 4 Hours	
High humidity and cool recoat and service times.	temperatures wi	ill result in longer dry,	
Dries By	Evap	oration, Coalescence	
Viscosity		108 ± 2 KU	
Flash Point		None	
Gloss / Sheen		Flat (1-5 @ 85°)	
Surface Temperature at Application	– Min. – Max	40°F 90°F	
Thin With		See Chart	

Volatile Organic Compounds (VOC)

– Min.

- Max

72.2 Grams/Liter .61 lbs./Gallon

[♦] Reported values are for Pastel Base. Contact Benjamin Moore for values of other bases or colors.

Surface Preparation

Surfaces to be stained must be clean, dry and free of dirt, mildew, oil or grease. Remove contaminants or chalky residue from weathered painted surfaces by washing with Benjamin Moore® Clean Multi-Purpose Cleaner (318). Excessive chalk must be removed by power wash equipment. Note: Smooth planed clapboards or siding must be sanded thoroughly or treated with Benjamin Moore® Brighten Brightener & Neutralizer (317) to break the "mill glaze" to allow proper penetration and adhesion.

Mildew: Stains from mildew must be removed by cleaning with Benjamin Moore® Clean (318) prior to coating the surface.

Painted Surfaces: Remove old scaling or peeling coatings by scraping, wire brushing and sanding. Glossy surfaces must be dulled by sanding. Un-weathered areas such as eaves, ceilings, or overhangs must be washed with a detergent solution and/or rinsed with a strong stream from a garden hose to remove surface salts that can interfere with proper adhesion.

Caution: Refer to the 317 and 318 technical data and material safety data sheets for instructions on their proper use and handling.

WARNING! If you scrape, sand or remove old paint, you may release lead dust. LEAD IS TOXIC. EXPOSURE TO LEAD DUST CAN CAUSE SERIOUS ILLNESS, SUCH AS DAMAGE, ESPECIALLY IN CHILDREN. PREGNANT WOMEN SHOULD ALSO AVOID EXPOSURE. Wear a NIOSH-approved respirator to control lead exposure. Carefully clean up with a HEPA vacuum and a wet mop. Before you start, find out how to protect yourself and your family by contacting the National Lead Information Hotline at 1-800-424-LEAD or log on to www.epa.gov/lead.

Primer/Finish Systems

Previously Stained, Painted, or Sealed Wood:

Primer: No priming necessary. **Finish:** 1 or 2 coats Arborcoat[®] WB Ultra Flat Solid Stain.

New Wood or Properly Prepared Weathered Wood:

Primer: Priming usually unnecessary. If light shades are applied to wood with high tannin levels, such as redwood and cedar, 1 coat of Arborcoat® Oil Primer (366) should be used before top coating to prevent bleeding. If unsure, test a small area prior to staining.

Finish: 2 coats Arborcoat® WB Ultra Flat Solid Stain.

Stucco and Masonry:

Primer: No priming necessary if the surface is in good condition. Loose, sandy masonry should be hosed down thoroughly to remove surface particles, allowed to dry and primed with Super Spec® Masonry Interior / Exterior 100% Acrylic Masonry Sealer (N/066). New masonry must be cured unless primed with Super Spec® Masonry Interior / Exterior 100% Acrylic Masonry Sealer (N/066).

Finish: 1 or 2 coats Arborcoat® WB Ultra Flat Solid Stain.

Repaint, All Substrates: Prime bare areas with the primer recommended for the substrate above.

Application

Mixing of paint: Immediately prior to use, the paint should be mixed thoroughly even though it has been shaken mechanically by the retailer. Preferred application method is by brushing. Roller application should be done only on rough or textured surfaces. To minimize lapping, always maintain a wet edge. On horizontal siding apply the stain on a section of 2 or 3 boards completely across the house. Lower the ladder and continue in the same manner until the side is completed. Vertical siding is coated using the same principle from top to bottom. Never stop staining in midwall; continue until a natural break is reached, such as a window. Refrain from staining in direct hot sun. Do not apply when air and surface temperatures are below 40°F (4.4°C), nor over damp surfaces or during threatening weather.

This product can also be sprayed. The Chart below is for general application guidance.

Thinning/Cleaning

Conditioning with Benjamin Moore [®] 518 Extender may be necessary under certain conditions to adjust open time or spray characteristics. The chart below is for general guidance			
	Mild conditions	Severe conditions	
	Humid (RH> 50%) with no direct sunlight & with little to no wind	Dry (RH<50%), in direct sunlight, or windy conditions	
Brush: Nylon / Polyester	No thinning necessary	Add 518 Extender or	
Roller : Aura [®] Roller Cover		water: Max of 8 fl. oz. to a gallon of paint	
Spray: Airless		Never add other paints or solvents.	

Clean Up: Wash painting tools in warm soapy water immediately after use. Spray equipment should be given a final rinse with mineral spirits to prevent rusting.

USE COMPLETELY OR DISPOSE OF PROPERLY. Dry, empty containers may be recycled in a can recycling program. Local disposal requirements vary; consult your sanitation department or state-designated environmental agency on disposal options.

Environmental Health & Safety Information

Use only with adequate ventilation. Do not breathe spray mist or sanding dust. Ensure fresh air entry during application and drying. Avoid contact with eyes and prolonged or repeated contact with skin. Avoid exposure to dust and spray mist by wearing a NIOSH approved respirator during application, sanding and clean up. Follow respirator manufacturer's directions for respirator use. Close container after each use. Wash thoroughly after handling.

WARNING: This product contains a chemical known to the state of California to cause cancer and birth defects, or other reproductive harm.

FIRST AID: In case of eye contact, flush immediately with plenty of water for at least 15 minutes; for skin, wash thoroughly with soap and water. If symptoms persist, seek medical attention. If you experience difficulty breathing, leave the area to obtain fresh air. If continued difficulty is experienced, get medical attention immediately.

IN CASE OF SPILL - Absorb with inert material and dispose of as specified under Thinning/Clean Up.

KEEP OUT OF REACH OF CHILDREN PROTECT FROM FREEZING

Refer to Safety Data Sheet for additional health and safety information.

Benjamin Moore & Co., 101 Paragon Drive, Montvale, NJ 07645 Tel: (201) 573-9600 Fax: (201) 573-9046 www.benjaminmoore.com M72 610 US 103114